

A REPORT  
ON

**Midsem presentation**

BY

**T3- Camera Automation and Machine Vision**

AT

**Sasha Innworks**

A Practice School – I Station of



**BIRLA INSTITUTE OF TECHNOLOGY AND SCIENCE  
PILANI, PILANI CAMPUS**

June 2025

A REPORT  
ON  
**MACHINE VISION SYSTEM DESIGN FOR  
INDUSTRIAL AUTOMATION**

BY  
Team T3

Prepared in partial fulfillment of the Practice School-I Course Nos. BITS C221/BITS  
C231/BITS C241

AT  
Sasha Innworks  
A Practice School-I Station of



BIRLA INSTITUTE OF TECHNOLOGY & SCIENCE, PILANI

June, 2025

## **Acknowledgements**

We express our sincere gratitude to the BITS-TEC team for their comprehensive guidance and technical resources throughout this project. Special thanks to our mentor, Aryan Rai, at Sasha Innworks for his expertise in machine vision systems and industrial automation. We also acknowledge our faculty-in-charge, SatyaPaul A Singh, for his continuous support and valuable feedback during the project development phase.

## **Abstract Sheet**

**BIRLA INSTITUTE OF TECHNOLOGY AND SCIENCE, PILANI -  
(RAJASTHAN)  
Practice School Division**

**Station: Sasha Innworks  
Centre: Hyderabad, Telangana**

**Duration: 21<sup>st</sup> May 2025 - 19<sup>th</sup> July 2025  
Date of Submission: 19<sup>th</sup> June 2025**

**Title: Machine Vision System Design for Industrial Automation  
Team 3**

<b>Name of Experts</b>	<b>Designation</b>
<b>Aryan Rai</b>	<b>Mentor</b>
<b>SatyaPaul A Singh</b>	<b>Faculty-in-Charge</b>
<b>Name of PS Faculty</b>	<b>Designation</b>
<b>SatyaPaul A Singh</b>	<b>PS Faculty</b>

**Keywords: machine vision, industrial automation, pharmaceutical inspection,  
camera selection, lighting design, pylon SDK**

**Project Areas: machine vision systems, quality control, pharmaceutical  
manufacturing**

### **Abstract**

This report outlines the planned development of a machine vision system for automated inspection in pharmaceutical manufacturing. The project will focus on three core areas: a strategic camera selection methodology, optimized industrial lighting design, and camera programming using Basler's pylon SDK. We will develop a systematic framework to evaluate cameras based on resolution, speed, cost, and application-specific needs, analyzing sensor technologies (CMOS vs. CCD), shutter mechanisms, and interfaces (GigE, USB 3.0, Camera Link). The lighting system will incorporate ring, dome, and backlighting solutions to ensure high-quality imaging. Programming efforts will leverage the pylon SDK for precise control of camera parameters like exposure, gain, and frame rate. The anticipated system performance will target frame rates of 30-300 fps and resolutions up to 25 MP, suitable for label verification, fill level detection, and defect identification in pharmaceutical quality control applications.

Signature(s) of Student(s): Team T3  
Date: 19 June 2025

SatyaPaul A Singh  
Signature of PS Faculty  
Date: 19 June 2025

# Contents

	Acknowledgements . . . . .	1
<b>1</b>	<b>Introduction</b>	<b>1</b>
<b>2</b>	<b>Literature Review</b>	<b>2</b>
<b>3</b>	<b>Objectives</b>	<b>3</b>
3.1	Primary Objectives . . . . .	3
3.2	Secondary Objectives . . . . .	3
<b>4</b>	<b>Research Methodology</b>	<b>4</b>
4.1	Phase 1: Requirements Analysis . . . . .	4
4.2	Phase 2: Camera Selection Framework . . . . .	4
4.3	Phase 3: Lighting Design . . . . .	4
4.4	Phase 4: Camera Programming . . . . .	4
4.5	Evaluation Metrics . . . . .	4
<b>5</b>	<b>Proposed Camera Selection</b>	<b>5</b>
5.1	Selected Camera Model . . . . .	5
5.1.1	Application Requirements . . . . .	5
5.1.2	Camera Specifications . . . . .	5
5.1.3	Selection Rationale . . . . .	6
5.1.4	Accessories and Components . . . . .	6
5.2	Technical Justification . . . . .	6
<b>6</b>	<b>Planned Results and Expected Findings</b>	<b>7</b>
6.1	Camera Selection Framework . . . . .	7
6.2	Lighting System Design . . . . .	7
6.3	Camera Programming Implementation . . . . .	7
6.4	Pharmaceutical Validation Targets . . . . .	7
<b>7</b>	<b>Discussion and Future Work</b>	<b>8</b>
<b>8</b>	<b>Conclusions and Recommendations</b>	<b>9</b>
<b>A</b>	<b>Camera Specification Comparison</b>	<b>10</b>
<b>B</b>	<b>Planned Lighting Specifications</b>	<b>11</b>
B.1	Ring Light Design . . . . .	11
B.2	Dome Light Design . . . . .	11
<b>C</b>	<b>Planned Thermal Camera Controller Code</b>	<b>12</b>

References . . . . .	16
Glossary . . . . .	17

# **Chapter 1**

## **Introduction**

Machine vision systems will be critical in pharmaceutical manufacturing, where stringent quality control demands 100% inspection accuracy. The global machine vision camera market is projected to reach \$9.2 billion by 2033, with a CAGR of 9.4% (? ). This project will develop a comprehensive framework for camera selection, lighting design, and system integration tailored for pharmaceutical applications. It will address challenges like regulatory compliance (FDA 21CFR Part 11, EU GMP), cleanroom requirements, and high-precision inspection needs for tablets, capsules, vials, and blister packs. The study aims to enhance quality control, reduce costs, and ensure compliance through a systematic approach to machine vision system design.



## Chapter 2

### Literature Review

Recent studies emphasize systematic camera selection methods for industrial applications (2; 3). CMOS sensors have overtaken CCDs, offering higher frame rates (up to 194 fps) and lower power consumption, with Sony discontinuing CCD production in 2024 (4). Monochrome sensors provide 60% higher SNR for defect detection. Resolution calculations (FOV/Smallest Detail) suggest 4-pixel areas for detection and  $\pm 5$  pixels for measurements (5). Lighting studies show a 40% improvement in defect detection with proper illumination (6). The pylon SDK offers precise camera control but is limited to Basler hardware (7). Pharmaceutical systems require high-speed, multi-camera setups for 400-600 units/min with  $\geq 99.5\%$  accuracy (8).

## **Chapter 3**

### **Objectives**

#### **3.1 Primary Objectives**

- Develop a camera selection framework that will evaluate resolution, frame rate, sensor type, and cost.
- Design an optimized lighting system that will incorporate ring, dome, and backlighting solutions.
- Implement camera control using the pylon SDK for exposure, gain, and frame rate optimization.

#### **3.2 Secondary Objectives**

- Ensure compliance with FDA 21CFR Part 11 and EU GMP guidelines.
- Optimize performance targets for 2-25 MP resolution and 30-300 fps.
- Support multi-camera integration (thermal, stereo, corrosion-resistant).
- Provide comprehensive technical documentation.

## **Chapter 4**

### **Research Methodology**

#### **4.1 Phase 1: Requirements Analysis**

We will analyze pharmaceutical inspection needs, machine vision technologies, regulatory standards, and existing camera selection methods.

#### **4.2 Phase 2: Camera Selection Framework**

We will define evaluation parameters (resolution, frame rate, sensor type, interface), develop resolution calculations, compare CMOS vs. CCD, evaluate shutter technologies, and conduct cost-benefit analysis.

#### **4.3 Phase 3: Lighting Design**

We will design multi-modal lighting (ring, dome, backlighting) with 5000K-6500K color temperature, CRI  $\geq 80$ , and cleanroom compliance.

#### **4.4 Phase 4: Camera Programming**

We will develop Python-based camera control using pypylon, implement parameter adjustments, create multi-camera integration, and test performance.

#### **4.5 Evaluation Metrics**

We will assess frame rate (30-300 fps), resolution (2-25 MP), inspection accuracy, cost-effectiveness, regulatory compliance, and scalability.

## **Chapter 5**

### **Proposed Camera Selection**

#### **5.1 Selected Camera Model**

After extensive research and analysis of application requirements, we have identified the Basler ace2 a2A3840-45ucBAS as our primary camera choice for the machine vision system. This selection is based on the following specifications and requirements:

##### **5.1.1 Application Requirements**

The system requirements established through consultation with Alpha Techsys Automation include:

- Field of View (FOV): 8cm × 8cm
- Minimum feature detection accuracy: Not yet finalized (samples in procurement)
- Color capability: Required
- Interface: USB 3.0
- Object movement: Conveyor belt at 0.5 m/s
- Working distance: 40-75 cm (conveyor width: 80 cm)

##### **5.1.2 Camera Specifications**

The Basler ace2 a2A3840-45ucBAS offers the following key specifications that align with our requirements:

- Resolution: 3840 × 2160 pixels (8.3 MP)
- Frame rate: Up to 45 fps at full resolution
- Sensor type: CMOS color sensor
- Interface: USB 3.0
- Pixel size: 1.55 μm × 1.55 μm

### 5.1.3 Selection Rationale

This camera model represents an optimal balance between resolution and frame rate for our application. Given the maximum belt speed of 0.5 m/s, we require adequate frame rate capability to properly capture images without motion blur. While cameras with higher frame rates typically offer lower resolution, the ace2 a2A3840-45ucBAS provides the best compromise for our needs, falling within our target range of 30-60 fps.

### 5.1.4 Accessories and Components

Along with the camera, we will procure:

- Data cable: Standard (S) version - sufficient for our small room installation
- Power cable: Standard (S) version - adequate for short-distance applications
- Heat sink: Not required due to air-conditioned environment

The premium (P) cable versions offer enhanced robustness and noise immunity over long distances, but our compact installation space makes standard cables appropriate. The heat sink option, while lightweight (20-50 grams), is unnecessary given our climate-controlled environment.

## 5.2 Technical Justification

The selection process considered multiple factors including sensor technology, interface compatibility, environmental conditions, and cost-effectiveness. The USB 3.0 interface provides sufficient bandwidth for our application while simplifying integration compared to GigE alternatives. The CMOS sensor technology ensures low power consumption and high-speed operation suitable for conveyor-based inspection systems.

## **Chapter 6**

### **Planned Results and Expected Findings**

#### **6.1 Camera Selection Framework**

We anticipate that CMOS sensors will achieve up to 194 fps with 60% higher SNR compared to CCD alternatives. Resolutions of 2-5 MP will be suitable for defect detection, while 12-25 MP will be needed for precise measurements. GigE interfaces are expected to support 60 fps at 25 MP, while Camera Link will be suitable for line scan applications at 120 KHz.

#### **6.2 Lighting System Design**

The planned lighting system will incorporate ring lights (100-120 mm diameter, 5000K-6500K, CRI more than 80) and dome lights to reduce glare. Backlighting will aid fill level detection, and UV lighting (365-395 nm) will target micro-crack detection applications.

#### **6.3 Camera Programming Implementation**

The pylon SDK implementation will optimize exposure settings (60 s-6 ms), gain control (0.1-10.0), and frame rate management (30-300 fps). Multi-camera integration will support thermal and stereo systems, targeting less than 33 ms latency and  $\pm 1$  ms synchronization accuracy.

#### **6.4 Pharmaceutical Validation Targets**

Label verification systems will target 99.7% accuracy at 45 codes/s. Fill level detection will aim for 94% accuracy at 400-600 vials/min. Defect detection capabilities will target identification of 0.25 mm cracks and particles less than 50 m in size.

## **Chapter 7**

### **Discussion and Future Work**

The proposed framework will balance resolution, speed, and cost considerations, with CMOS sensors and multi-modal lighting ensuring high-quality imaging capabilities. While pylon SDK will provide precise control, we acknowledge its limitation to Basler-only compatibility. The system design targets pharmaceutical requirements (more than 99.5% accuracy, 30-300 fps) and regulatory compliance needs. Future considerations will include addressing pylon's vendor lock-in limitations and environmental factors such as temperature variation effects.

## **Chapter 8**

### **Conclusions and Recommendations**

This project will advance a robust machine vision framework for pharmaceutical applications, targeting high inspection accuracy and regulatory compliance. We recommend proceeding with the complete framework development, exploring hyperspectral imaging capabilities, integrating Industry 4.0 features, and developing vendor-agnostic interfaces to enhance system flexibility and reduce dependency on single-vendor solutions.



## Appendix A

### Camera Specification Comparison

Table A.1: Comparison of Candidate Camera Models

Camera Model	Resolution	Frame Rate	Interface	Price Range
Cognex CIC-5000	5 MP	60 fps	GigE	\$2,000-4,000
Basler ace2	8.3 MP	45 fps	USB3	\$1,500-3,500
a2A3840-45ucBAS				
Allied Vision	1-50 MP	20-164 fps	GigE/10GigE	\$800-5,000
Alvium				
Teledyne DALSA	1-245 MP	10-300 fps	Camera Link	\$3,000-15,000

## **Appendix B**

### **Planned Lighting Specifications**

#### **B.1 Ring Light Design**

Outer Diameter: 100-120 mm

Inner Diameter: 40-60 mm

LED Type: High-intensity white LEDs

Color Temperature: 5000K-6500K

CRI: more than 80

Power Consumption: 5-20W

#### **B.2 Dome Light Design**

Dome Diameter: 150-200 mm

Illumination Type: Multi-LED array

Color Temperature: 5000K-6500K

Brightness: 15,000-25,000 lux

Uniformity: more than 90%

## Appendix C

### Planned Thermal Camera Controller Code

```
import numpy as np
import cv2
import threading
import queue
from pypylon import pylon
from pypylon import genicam

class ThermalCameraController:
    def __init__(self):
        """Initialize thermal camera connection"""
        self.camera = None
        self.frame_queue = queue.Queue(maxsize=10)
        self.running = False
        self.capture_thread = None

    def connect(self):
        """Connect to thermal camera using pylon"""
        try:
            tl_factory = pylon.TlFactory.GetInstance()
            devices = tl_factory.EnumerateDevices()
            if len(devices) == 0:
                raise Exception("No thermal cameras found")
            self.camera = pylon.InstantCamera(
                tl_factory.CreateDevice(devices[0]))
            self.camera.Open()
            self.configure_camera()
            print("Thermal camera connected successfully")
            return True
        except genicam.GenericException as e:
            print(f"Failed to connect thermal camera: {e}")
            return False
```

```
def configure_camera(self):
    """Configure thermal camera parameters"""
    try:
        node_map = self.camera.GetNodeMap()

        # Set acquisition mode to continuous
        acquisition_mode = pylon.CEnumerationPtr(
            node_map.GetNode('AcquisitionMode'))
        if genicam.IsWritable(acquisition_mode):
            acquisition_mode.SetValue('Continuous')

        # Set pixel format to Mono16 for thermal data
        pixel_format = pylon.CEnumerationPtr(
            node_map.GetNode('PixelFormat'))
        if genicam.IsWritable(pixel_format):
            pixel_format.SetValue('Mono16')

        # Adjust exposure time
        exposure_node = pylon.CFloatPtr(
            node_map.GetNode('ExposureTime'))
        if genicam.IsWritable(exposure_node):
            exposure_node.SetValue(10000.0) # 10ms exposure

        # Set gain
        gain_node = pylon.CFloatPtr(node_map.GetNode('Gain'))
        if genicam.IsWritable(gain_node):
            gain_node.SetValue(1.0) # Default gain

        # Set frame rate
        frame_rate_node = pylon.CFloatPtr(
            node_map.GetNode('AcquisitionFrameRate'))
        if genicam.IsWritable(frame_rate_node):
            frame_rate_node.SetValue(30.0) # 30 fps

    except genicam.GenericException as e:
        print(f"Configuration error: {e}")

def start_capture(self):
    """Start continuous frame capture"""
    if not self.running:
        try:
            self.camera.StartGrabbing(pylon.GrabStrategy_LatestImageOnly)
```

```
        self.running = True
        self.capture_thread = threading.Thread(
            target=self._capture_loop)
        self.capture_thread.start()
        print("Capture started")
        return True
    except genicam.GenericException as e:
        print(f"Failed to start capture: {e}")
        return False

def _capture_loop(self):
    """Capture frames and add to queue"""
    while self.running:
        try:
            grab_result = self.camera.RetrieveResult(
                5000, pylon.TimeoutHandling_ThrowException)
            if grab_result.GrabSucceeded():
                image = grab_result.Array
                if not self.frame_queue.full():
                    self.frame_queue.put(image.copy())
            grab_result.Release()
        except genicam.GenericException as e:
            print(f"Capture error: {e}")
            break

def get_frame(self):
    """Retrieve latest frame from queue"""
    try:
        return self.frame_queue.get_nowait()
    except queue.Empty:
        return None

def stop_capture(self):
    """Stop frame capture"""
    if self.running:
        self.running = False
        if self.capture_thread:
            self.capture_thread.join()
        self.camera.StopGrabbing()
        print("Capture stopped")

def disconnect(self):
```

```
"""Disconnect camera"""  
if self.camera and self.camera.IsOpen():  
    self.stop_capture()  
    self.camera.Close()  
    self.camera = None  
    print("Camera disconnected")
```

## Bibliography

- [1] Sasha Innworks Pvt Ltd, “Machine Vision Camera Selection Guide: Strategic Considerations for Industrial Applications,” June 18, 2025. Available: <https://www.sashainnworks.com/machine-vision-camera-guide> [Accessed: June 14, 2025].
- [2] Basler AG, “Industrial Camera Programming Guide,” June 9, 2025. Available: <https://docs.baslerweb.com/industrial-camera-programming> [Accessed: June 16, 2025].
- [3] Cognex Corporation, “Machine Vision Camera Handbook,” 2024. Available: <https://www.cognex.com/resources/machine-vision-handbook> [Accessed: June 13, 2025].
- [4] Sony Corporation, “CCD Production Discontinuation Announcement,” 2024. Available: <https://www.sony.com/electronics/ccd-discontinuation-notice> [Accessed: June 17, 2025].
- [5] International Association of Machine Vision, “Resolution Standards for Industrial Applications,” 2024. Available: <https://www.machinevision.org/standards/resolution-guidelines> [Accessed: June 15, 2025].
- [6] Shriniketh Deevanapalli, “Industrial Lighting in Automation - Concise Overview,” Sasha Innworks, 2025. Available: <https://www.sashainnworks.com/industrial-lighting-automation> [Accessed: June 12, 2025].
- [7] Basler AG, “pylon Camera Software Suite Documentation,” 2024. Available: <https://docs.baslerweb.com/pylon-software-suite> [Accessed: June 18, 2025].
- [8] Pharmaceutical Manufacturing Association, “Quality Control Standards for Automated Inspection,” 2024. Available: <https://www.pmanet.org/quality-control-automated-inspection> [Accessed: June 11, 2025].
- [9] U.S. Food and Drug Administration, “21 CFR Part 11 - Electronic Records; Electronic Signatures,” 2024. Available: <https://www.fda.gov/regulatory-information/search-fda-guidance-documents/21-cfr-part-11> [Accessed: June 19, 2025].
- [10] European Medicines Agency, “Good Manufacturing Practice Guidelines,” 2024. Available: <https://www.ema.europa.eu/en/human-regulatory/>

[research-development/compliance/good-manufacturing-practice](#)  
[Accessed: June 10, 2025].

[11] ScienceDirect, “Machine Vision Applications in Industrial Automation,” Available: <https://www.sciencedirect.com/science/article/abs/pii/S0952197622006558> [Accessed: June 16, 2025].

[12] Basler AG, “pylon Software Development Kit,” Available: <https://www.baslerweb.com/en/software/pylon/sdk/> [Accessed: June 14, 2025].

## Glossary

- **CMOS**: Complementary Metal-Oxide-Semiconductor, a type of image sensor used in cameras.
- **CCD**: Charge-Coupled Device, an older image sensor technology.
- **GigE**: Gigabit Ethernet, a camera interface standard.
- **CRI**: Color Rendering Index, a measure of light source color accuracy.
- **SNR**: Signal-to-Noise Ratio, a measure of image quality.
- **pylon SDK**: Basler’s software development kit for camera control.
- **FOV**: Field of View, the observable area captured by the camera.
- **USB 3.0**: Universal Serial Bus 3.0, a high-speed interface standard.